


TSE02B



USER MANUAL Bidet Seat

WWW.WINFIELDPRODUCT.COM

Contents

- Thank you for you purchasing our washing cover plate.
 please read the manual carefully and use product correctly
- Please keep it in a convenient place

Installation steps 4

Product technical specification 7
Faults and solutions 7
Cleaning and maintenance 8
Warranty Card 10

Read the safety instructions carefully before use so as to properly use the product. Note the following warnings relevant to the safety.



Do not place heavy objects on the toilet seat or the toilet cover



Do not disassemble, repair and modify products by without authorization.





Do not place this product in direct sunlight.




Do not bend or twist the water supply hose.



Do not lean against the toilet lid when in use




The room temperature of toilet shall be above 0°C.




Do not connect to the substandard water pipe.



Please clean with the diluted kitchen cleaning agent and do not use the following items:Benzene, paint thinner, detergent powder, nylon brush, etc.




Product dimension drawing



1.Cover plate



2. Installation template



3.Fixation part









Plastic TAB(2)



Fixing plate



Rubber bushing(2)

4.Adapter



5. Water inlet hose



6. User manual



Installation tools



Attention before installation


- 1.Water pressure range: 0.1-0.75MPa, please follow the instructions.
- Corner valves shall be located close to the location where this product is installed and disassembled.
- 3. Please use the braided hose that comes with the product to prevent water leakage.
- 4. When installing braided hose, be careful to prevent the black gasket falling out.


• Installation Procedure

1.Loosen the nut connecting and remove the old cover.




Place the mounting template on the ceramic as shown. Align it with the rim of toilet.






- 3. ①Insert the expansion bolt into ceramic hole;
 - ②Place fixing plate in notch part of template;
 - 3 Place adjusting sheet and plate in fixing plate;
 - 4 Align expansion bolt hole, and tighten up;
- 5.Slightly push the cover into fixing plate until you heard "click", indicating that the cover has been installed in place.



6.Close the water valve;




7.Install braided hose;






 $\ \ \,$ $\ \ \,$ $\ \ \,$ $\ \ \,$ $\ \ \,$ $\ \$






②When the ceramic is similar to the figure above,we suggest connecting the elbow end of the hose to the cover

8. Connecting flexible hose;




9. Open the vavle to check water leakage;



Installation steps

10. Turn on the knob to check whether the nozzle is protruding;







- 1. It is strictly prohibited to move the product from the toilet cover, otherwise easy to cause mechanical failure.
- Prohibition 2. It is strictly prohibited to connect hot water above 40 C and cold water that may lead to icing.

Function introduction

Konb functin

1. Rinse functin





Bidet/Hip rinsing

Rotating knob to adjust amount of water

Note: Please open the knob to the maximum before use,and then adjust the amount of water and rinsing force through the konb.

Items		Description	
Model		TSE02B	
Water supply pressure		0.1 ~ 0.75MPa	
Water supply temperature		5 ~ 35°C	
Ambient temperature		0 ~ 40°C	
Net weight		About 2.2kg	
Package dimensions		525×395×110mm	
Cleaning device	Water amount regulation	Stepless regulation	
	Anti-backflow device	Anti-siphon valve	
Others	Antibacterial material	Nozzle and seat	
	Control operation	Knob	


Faults and solutions

Phenomenon	Possible cause	Solution	
	Knob is not completely turned on.	Increase knob regulating angle.	
Low flushing	Water pressure too low	Contact relevant departments to solve water pressure problems	
	Vavle off	Open the vavle	
Turn on knob and no the water comes out	The filter of the water inlet pipe is blocked	Clean the filter of the water inlet pipe	
	Nozzle clogging	Remove the nozzle and clean	
Spary rod cannot reset	Water quality is too bab to blocking the spary rod	Clean spary rod	
Base leaking	Water pressure too high	Contact relevant departments to solve water pressure problems	

Cleaning and maintenance

Manual cleaning of spray tube

- Gently pull out the nozzle and dip the neutral detergent with a soft cloth, sponge or small brush.
- Gently support the nozzle, wipe the spray tube and nozzle.





- Make sure that the corner valve close off before you clean the filter screen;
- Clean the filter screen when the water flow is less than normal hours.
- During cleaning process, the product must be thoroughly separated from the water inlet hose;
- Reinstall the filter screen in reverse order after cleaning.

• Product surface cleaning

- Wipe the product surface with a sponge or soft cloth dampened with room temperature water or a neutral detergent.
- Lift the upper cover and the seat ring when cleaning other parts with cleaning agents.
- Do not put cover on before the cleaning agent in the ceramic toilet is completely washed, otherwise the surface may be corroded by the evaporation of cleaning agent.



Winfield Products

1689 E. Mission Blvd., Pomona, CA 91766 support@winfieldproduct.com www.winfieldproduct.com